


# GREY SLATE AMBER 3' BED ASSEMBLY INSTRUCTIONS




MAX WEIGHT



## **IMPORTANT FOR DOMESTIC USE ONLY PLEASE READ BEFORE YOU CONTINUE FURTHER CARE AND MAINTENANCE**

- After unpacking this product please keep the original packaging in case it needs to be returned for any reason.
- Please ensure all fittings and parts are present before commencing with assembly.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- We strongly recommend that you keep children away from your work area.
- Assemble this product as close to its final position as possible.
- Never drag or push products as this could cause damage to the joints making it inferior.
- Do not drag or push items across your furniture as this may cause the surface to scratch.
- Do not place this product next to a radiator or in direct sunlight.
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or microfibre cloth, and do not use detergents of any kind.
- Do not place on a wet or damp floor as staining may occur to your floor.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.



\* Use of power tools to assemble this product will invalidate any claim and damage this product making it unsafe !!!  
 \* Please assemble on a clean soft surface to avoid damage.









\* Please check contents and read the instructions before commencing assembly.  
 \* Assemble this product following the enclosed instructions carefully.  
 \* Please take care to avoid damaging panels during assembly.

**Please Note:**  
 The below highlighted parts have been number/colour coded to help identify them during assembly.





### PARTS LIST

Part Number	Part Code	Part Description	Quantity	Carton
01	S200-201-066-DC1-01	Upper Crossbeam	1	1/2
02	S200-201-066-DC1-02	Large Panel	1	1/2
03	S200-201-066-DC1-03	Lower Crossbeam	1	1/2
04	S200-201-066-DC1-04	Small Panel	1	1/2
05	S200-201-066-DC1-05	Slats (02 Holes)	13	1/2
06	S200-201-066-DC1-06	Siderails	2	2/2
07	S200-201-066-DC1-07	Right Headboard Post (Natural)	1	1/2
08	S200-201-066-DC1-08	Left Headboard Post (Green)	1	1/2
09	S200-201-066-DC1-09	Left Footboard Post (Green)	1	1/2
10	S200-201-066-DC1-10	Right Footboard Post (Natural)	1	1/2

### FITTINGS

A	 17mm    Ø1/4 x 90mm	04	F	 SPACER	02
B	 1/4	04	G <sup>2/+</sup>	 Ø8 x 50mm	16
C	 Ø3,5 x 30mm	26	H	 GLUE	01
D	 17mm    Ø7 x 100mm	08			
E		01			

### TOOLS REQUIRED



# STEP 1

## PARTS REQUIRED


01- UPPER CROSSBEAM x1

03- LOWER CROSSBEAM x1

07- RIGHT HEADBOARD POST (NATURAL) x1

08- LEFT HEADBOARD POST (GREEN) x1



## HARDWARE REQUIRED


G  04  
Ø8 x 50mm

H  01  
GLUE

## TOOLS REQUIRED

 Please assemble on a clean soft surface to avoid damage.



 Glue must be added to the dowel holes on part 01,03,07 and 08.

# STEP 2


## PARTS REQUIRED

01- UPPER CROSSBEAM x1




03- LOWER CROSSBEAM x1

07- RIGHT HEADBOARD POST (NATURAL) x1

## HARDWARE REQUIRED

D  02  
17mm Ø7 x 100mm

## TOOLS REQUIRED




 Please assemble on a clean soft surface to avoid damage.

# STEP 3


## PARTS REQUIRED

02- LARGE PANEL x1



## HARDWARE REQUIRED

## TOOLS REQUIRED




**!**  
Please assemble on a clean soft surface to avoid damage.



# STEP 4

## PARTS REQUIRED



08- LEFT HEADBOARD POST (GREEN) x1



## HARDWARE REQUIRED

D  17mm  Ø7 x 100mm 02

## TOOLS REQUIRED





**!**  
Please assemble on a clean soft surface to avoid damage.

# STEP 5

## PARTS REQUIRED



- 04- SMALL PANEL x1
- 09- LEFT FOOTBOARD POST (GREEN) x1
- 10- RIGHT HEADBOARD POST (NATURAL) x1


## HARDWARE REQUIRED

- G  Ø8 x 50mm 04
- H  GLUE 01

## TOOLS REQUIRED

 Please assemble on a clean soft surface to avoid damage.




 Glue must be added to the dowel holes on part 04, 09 and 10.

# STEP 6





## PARTS REQUIRED

- 04- SMALL PANEL x1
- 10- RIGHT FOOTBOARD POST (NATURAL) x1

## HARDWARE REQUIRED

- D  17mm Ø7 x 100mm 02

## TOOLS REQUIRED




 Please assemble on a clean soft surface to avoid damage.


# STEP 7

## PARTS REQUIRED



09 - LEFT FOOTBOARD POST (GREEN) X1



## HARDWARE REQUIRED



## TOOLS REQUIRED



**Please assemble on a clean soft surface to avoid damage.**

# STEP 8


## PARTS REQUIRED

06- SIDERAILS x2

## HARDWARE REQUIRED




## TOOLS REQUIRED




# STEP 9

## PARTS REQUIRED

06- SIDERAILS x2





## HARDWARE REQUIRED

A  04  
17mm Ø1/4 x 90mm

B  04  
1/4


## TOOLS REQUIRED




# STEP 10

## PARTS REQUIRED

05- SLATS (02 HOLES) x13





## HARDWARE REQUIRED

C  26  
Ø3,5 x 30 mm

F  02  
SPACER

## TOOLS REQUIRED



**!**  
Please fix the first slats adjacent to the headboard and footboard and work towards the middle of the bed using the spacer ( F ) as shown to ensure correct spacing. Fix all the slats to one siderail first then push the second siderail tight against the slats and fix.





MAX WEIGHT

