PANAMA 1 DRAWER COFFEE TABLE ASSEMBLY INSTRUCTIONS



IMPORTANT PLEASE READ BEFORE YOU CONTINUE FURTHER FOR DOMESTIC USE ONLY CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

• Please ensure all fittings and parts are present before commencing with assembly.

• We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.

- We strongly recommend that you keep children away from your work area.
- Assemble this product as close to its final position as possible.

• Never drag or push products as this could cause damage to the joints making it inferior.

• Do not place this product next to a radiator or in direct sunlight.

• Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.


Make sure any spillage is wiped off immediately.

• Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.

• For general cleaning use a duster, and do not use detergents of any kind. However, the surface will need to be retreated from time to time. This can be done by using block wax (unperfumed) and rubbing it over the whole item.

• From time to time it may be necessary to tighten fittings, regular inspections should be carried out.


SEC/SH/02/21/PJ1



PARTS LIST

Part Code	Part Description	Quantity	<u>Carton</u>
S300-301-024-PJ1-01	Front Frame	1	1/1
S300-301-024-PJ1-02	Back Panel	1	1/1
S300-301-024-PJ1-03	Side Panel	2	1/1
S300-301-024-PJ1-04	Leg	4	1/1
S300-301-024-PJ1-05	Top Panel	1	1/1
S300-301-024-PJ1-06	Right Drawer Runner	1	1/1
S300-301-024-PJ1-07	Left Drawer Runner	1	1/1
S300-301-024-PJ1-08	Drawer Front	1	1/1
S300-301-024-PJ1-09	Drawer Side	2	1/1
S300-301-024-PJ1-10	Drawer Bottom	1	1/1
S300-301-024-PJ1-11	Drawer Back	1	1/1
	S300-301-024-PJ1-01 S300-301-024-PJ1-02 S300-301-024-PJ1-03 S300-301-024-PJ1-04 S300-301-024-PJ1-05 S300-301-024-PJ1-06 S300-301-024-PJ1-07 S300-301-024-PJ1-08 S300-301-024-PJ1-09 S300-301-024-PJ1-10	S300-301-024-PJ1-01 Front Frame S300-301-024-PJ1-02 Back Panel S300-301-024-PJ1-03 Side Panel S300-301-024-PJ1-04 Leg S300-301-024-PJ1-05 Top Panel S300-301-024-PJ1-06 Right Drawer Runner S300-301-024-PJ1-07 Left Drawer Runner S300-301-024-PJ1-07 Drawer Front S300-301-024-PJ1-08 Drawer Side S300-301-024-PJ1-09 Drawer Side	S300-301-024-PJ1-01 Front Frame 1 S300-301-024-PJ1-02 Back Panel 1 S300-301-024-PJ1-03 Side Panel 2 S300-301-024-PJ1-04 Leg 4 S300-301-024-PJ1-05 Top Panel 1 S300-301-024-PJ1-06 Right Drawer Runner 1 S300-301-024-PJ1-06 Right Drawer Runner 1 S300-301-024-PJ1-07 Left Drawer Runner 1 S300-301-024-PJ1-08 Drawer Front 1 S300-301-024-PJ1-09 Drawer Side 2 S300-301-024-PJ1-10 Drawer Bottom 1

SEC/SH/02/21/PJ1



TOOLS REQUIRED

