
55221

Corona Corner TV Cabinet

ASSEMBLY INSTRUCTIONS








IMPORTANT

FOR DOMESTIC USE ONLY
PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- We strongly recommend that you keep children away from your work area.
- Assemble this product as close to its final position as possible.
- Never drag or push products as this could cause damage to the joints making it inferior.
- Do not place this product next to a radiator or in direct sunlight.
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped o ffimmediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a duster, and do not use detergents of any kind. However, the surface will need to be retreated from time to time. This can be done by using block wax (unperfumed) and rubbing it over the whole item.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.



1	Right Side Panel	01
2	Base	01
3	Fixed Shelf	01
4	Left Side Panel	01
5	Front Frame	01
6	Left Side Back Upright	01
7	Right Side Back Upright	01
8	Top Panel	01

9	Side Plinth	02
10	Left Door	01
11	Right Door	01
12	Door Strip	01
13	Front Plinth	01
14	Small Back Panel	02
15	Large Back Panel	01
16	Hardware Kit	01

PAGE 2


FITTINGS



- * Please check contents and read the instructions before commencing assembly.
- * Assemble this product following the enclosed instructions carefully.
- * Please take care to avoid damaging parts during assembly.

A	€ 3,5x35	31
B		02
C	3,5x16	35
		02


\mathbb{E}	10x10	30
F	8x30	22
G		06
Н		04
I	0) _{2x}	01





* Use of power tools to assemble this product will invalidate any claim and could damage this product making it unsafe!!!


* Please assemble on a clean soft surface to avoid damage.

PAGE 3









WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.

- HARDWARE LIST



Strap (Anti-Tip Kit) (1x)

$\bigoplus \dots \bigoplus$

Wood Screw (Anti-Tip Kit) 3,5 x 25mm (1x)

Washer (Anti-Tip Kit)

