


will occur.
For general cleaning use a duster, and do not use detergents of any kind. However, the surface will need to be retreated from time to time. This can be done by using block wax

(unperfumed) and rubbing it over the whole item.

•From time to time it may be necessary to tighten fittings, regular inspections should be carried out. PAGE 1





## FITTINGS





\* Please check contents and read the instructions before commencing assembly. \*Assemble this product following the enclosed instructions carefully.


\* Please take care to avoid damaging parts during assembly.


























## WARNING

## Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.

