


# VERMONT 2 DOOR WARDROBE

## ASSEMBLY INSTRUCTIONS

### WHITE/GREY

55121




### IMPORTANT FOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER

## CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.
























### PARTS LIST

**Please Note:**  
The below parts have all been stamped with the part number to help identify them during assembly.


Part Number	Part Code	Part Description	Quantity	Carton
1	S100-101-092-DV1-01	Front Left Upright	1	1/2
2	S100-101-092-DV1-02	Left Side Panel	1	1/2
3	S100-101-092-DV1-03	Left Rear Upright	1	2/2
4	S100-101-092-DV1-04	Shelf	1	1/2
5	S100-101-092-DV1-05	Base Panel	1	1/2
6	S100-101-092-DV1-06	Crossbeam	1	2/2
7	S100-101-092-DV1-07	Right front upright	1	1/2
8	S100-101-092-DV1-08	Right Side Panel	1	1/2
9	S100-101-092-DV1-09	Rear Right Upright	1	2/2
10	S100-101-092-DV1-10	Top Panel	1	1/2
11	S100-101-092-DV1-11	Back Panel	2	2/2
12	S100-101-092-DV1-12	Hanging Rail	1	1/2
13	S100-101-092-DV1-13	Back Panel Strip - Lower	1	1/2
14	S100-101-092-DV1-14	Door	2	2/2

## FITTINGS LIST


<p><b>A</b></p>  <p style="text-align: center;">Glue (2x)</p>	<p><b>B</b></p>  <p style="text-align: center;">2/+ Dowel Ø6,0 x 30mm (26x)</p>	<p><b>C</b></p>  <p style="text-align: center;">1/+ Cam Nut (14x)</p>	<p><b>D</b></p>  <p style="text-align: center;">Handle(2x)</p>
<p><b>E</b></p>  <p style="text-align: center;">CH PHS ZP 3/16X3/4 (2x)</p>	<p><b>F</b></p>  <p style="text-align: center;">Hinge (6x)</p>	<p><b>G</b></p>  <p style="text-align: center;">2/+ Nail 10 x 10 (54x)</p>	
<p><b>H</b></p>  <p style="text-align: center;">2/+ Flat Head Screw Ø3,5 x 16mm (30x)</p>	<p><b>I</b></p>  <p style="text-align: center;">2/+ Hole Plugs (40x)</p>	<p><b>J</b></p>  <p style="text-align: center;">1/+ Cam Bolt (14x)</p>	<p><b>K</b></p>  <p style="text-align: center;">Hanging Rail (2x)</p>
<p><b>L</b></p>  <p style="text-align: center;">2/+ Flat Head Screw Ø3,5 x 10mm (16x)</p>	<p><b>M</b></p>  <p style="text-align: center;">Metalic Support (1x)</p>	<p><b>N</b></p>  <p style="text-align: center;">Roller Clasp (4x)</p>	
<p><b>O</b></p>  <p style="text-align: center;">Roller Clasp (4x)</p>	<p><b>P</b></p>  <p style="text-align: center;">1727 mm Back Panel Strip (1x)</p>	<p><b>R</b></p>  <p style="text-align: right;">Ø3,5x25    <b>01</b></p>  <p style="text-align: right;">Washer    <b>02</b></p>  <p style="text-align: right;">Anti-tip strap    <b>01</b></p>	
<p><b>Q</b></p>  <p style="text-align: center;">2/+ Flat Head Screw Ø3,5 x 25mm (20x)</p>			
<p><b>S</b></p>  <p style="text-align: center;">2/+ Flat Head Screw Ø3,5 x 10mm (6x)</p>			

### TIPS FOR FITTINGS CAM-LOCKS


WHEN FITTING CAM NUT. ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE



↑  
**CORRECT**




↑  
**WRONG**



**Cam bolt head needs to be in centre**

**CAMBOLT**

**Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)**







# STEP 1




## PARTS REQUIRED

4 - SHELF	x1
5 - BASE PANEL	x1
6 - CROSSBEAM	x1

## HARDWARE REQUIRED

A		01
B		10
M		01
S		01

## TOOLS REQUIRED






# STEP 2




## PARTS REQUIRED

5 - BASE PANEL	x1
10 - TOP PANEL	x1

## HARDWARE REQUIRED

L		08
J		04
O		04

## TOOLS REQUIRED





# STEP 3



## PARTS REQUIRED

- 1 - FRONT LEFT UPRIGHT x1
- 3 - LEFT REAR UPRIGHT x1
- 7 - RIGHT FRONT UPRIGHT x1
- 9 - REAR RIGHT UPRIGHT x1

## HARDWARE REQUIRED

- A  01
- B  Ø6.0 x 30mm 12

## TOOLS REQUIRED





# STEP 4



## PARTS REQUIRED

- 1 - FRONT LEFT UPRIGHT x1
- 2 - LEFT SIDE PANEL x1

## HARDWARE REQUIRED

- I  08
- Q  Ø3.5 x 25mm 05

## TOOLS REQUIRED







# STEP 5




## PARTS REQUIRED

- 2 - LEFT SIDE PANEL x1
- 3 - LEFT REAR UPRIGHT x1


## HARDWARE REQUIRED

- A  01
- B  Ø6,0 x 30mm 02
- I  08
- Q  Ø3,5 x 25mm 05


## TOOLS REQUIRED



Detail 1



Detail 5






Detail 15

# STEP 6




## PARTS REQUIRED

- 2 - LEFT SIDE PANEL x1


## HARDWARE REQUIRED

- K  01
- S  Ø3,5 x 10mm 02
- J  05


## TOOLS REQUIRED




Detail 6



Detail 6



Detail 4



# STEP 7


## PARTS REQUIRED

7 - RIGHT FRONT UPRIGHT x1



8 - RIGHT SIDE PANEL x1

## HARDWARE REQUIRED

I  08

Q  Ø3,5 x 25mm 05

## TOOLS REQUIRED



# STEP 8


## PARTS REQUIRED

8 - RIGHT SIDE PANEL x1


9 - REAR RIGHT UPRIGHT x1

## HARDWARE REQUIRED




A  Glue 01

B  Ø6,0 x 30mm 02

I  08

Q  Ø3,5 x 25mm 05

## TOOLS REQUIRED



# STEP 9


## PARTS REQUIRED

8 - RIGHT SIDE PANEL x1




## HARDWARE REQUIRED

J  05


K  01

S  02  
Ø3,5 x 10mm


## TOOLS REQUIRED




Detail 6



Detail 6



Detail 4



# STEP 10

## PARTS REQUIRED

2 - LEFT SIDE PANEL x1

4 - SHELF x1

5 - BASE PANEL x1

6 - CROSSBEAM x1




## HARDWARE REQUIRED

A  01


C  05

I  02


## TOOLS REQUIRED



Detail 16



Detail 7




Cam bolt head needs to be in centre




# STEP 11

## PARTS REQUIRED

8 - RIGHT SIDE PANEL x1








## HARDWARE REQUIRED

A  01

C  05

I  02


## TOOLS REQUIRED



# STEP 12

## PARTS REQUIRED

10 - TOP PANEL x1



## HARDWARE REQUIRED







A  01

C  04

I  04

S  Ø3.5 x 10mm 01


## TOOLS REQUIRED




# STEP 13


**PARTS REQUIRED**

11 - BACK PANEL x2





**HARDWARE REQUIRED**

G  48


P  01

**TOOLS REQUIRED**




# STEP 14



**PARTS REQUIRED**



**HARDWARE REQUIRED**

G  06


**TOOLS REQUIRED**



# STEP 15



**PARTS REQUIRED**

12 - HANGING RAIL x1



**HARDWARE REQUIRED**

**TOOLS REQUIRED**




Detail 10


# STEP 16


**PARTS REQUIRED**

14 - DOOR x2

**HARDWARE REQUIRED**


F  06

H  12  
Ø3,5 x 16mm



L  08  
Ø3,5 x 10mm

N  04


**TOOLS REQUIRED**




PLEASE NOTE  
PRE-DRILLED  
HOLES.




Detail



Detail 12



Detail 12




Detail 13

# STEP 17

## PARTS REQUIRED

14 - DOOR x2




## HARDWARE REQUIRED

D 02

E 02  
CH PHS ZP 3/16X3/4



H 18  
Ø3,5 x 16mm

## TOOLS REQUIRED




**TIP**  
If desired, after assembly use an alcohol cleaner to erase the number printed on the parts.

PLEASE NOTE PRE-DRILLED HOLES.




Detail 14



# STEP 18




## PARTS REQUIRED



## HARDWARE REQUIRED

R 01

## TOOLS REQUIRED



## WARNING

**Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.**

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.