




# BROOKLYN 3 DOOR 2 DRAWER WARDROBE ASSEMBLY INSTRUCTIONS



## **IMPORTANT FOR DOMESTIC USE ONLY PLEASE READ BEFORE YOU CONTINUE FURTHER**

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTINGS KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE. DO NOT OVERTIGHTEN FIXING.

FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET) DO NOT USE POLISH, DETERGENT OR CHEMICAL CLEANERS.


























THE SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.




## PART LIST

<u>Part Number</u>	<u>Part Code</u>	<u>Part Description</u>	<u>Quantity</u>	<u>Carton</u>
1	S100-101-192-EU1-01	Centre Panel	1	1/3
2	S100-101-192-EU1-02	Large Shelf Panel	1	2/3
3	S100-101-192-EU1-03	Side Panel - Left	1	1/3
4	S100-101-192-EU1-04	Side Panel - Right	1	1/3
5	S100-101-192-EU1-05	Top Panel	1	2/3
6	S100-101-192-EU1-06	Bottom Panel	1	2/3
7	S100-101-192-EU1-07	Back Panel 1	2	2/3
8	S100-101-192-EU1-08	Back Panel 2	2	2/3
9	S100-101-192-EU1-09	Drawer Back	2	3/3
10	S100-101-192-EU1-10	Drawer Side - Left	2	3/3
11	S100-101-192-EU1-11	Drawer Side - Right	2	3/3
12	S100-101-192-EU1-12	Drawer Front	2	3/3
13	S100-101-192-EU1-13	Drawer Base	2	2/3
14	S100-101-192-EU1-14	Drawer Bottom Support Rail	2	3/3
15	S100-101-192-EU1-15	Small Door 1	1	3/3
16	S100-101-192-EU1-16	Small Door 2	1	3/3
17	S100-101-192-EU1-17	Large Door Mirror	1	3/3
18	S100-101-192-EU1-18	Small Shelf Panel	3	2/3


## HARDWARE LIST

A		DOWEL 6 X 30MM	32 PCS	O		DRAWER RUNNER A - L/R	4 PCS
B		BOLT M6 X 50MM	4 PCS	P		DRAWER RUNNER B - L/R	4 PCS
C		SCREW M6 X 50MM	12 PCS	Q		SCREW M4 X 30MM	4 PCS
D		SCREW M3.5 X 16MM	33 PCS	R		HANDLE SCREW 19MM	5 PCS
E		TACK	52 PCS	S		SCREW M3.5 X 12MM	36 PCS
F		SCREW M4 X 50MM	20 PCS	T		CAM BOLT + CAM NUT	6 SETS
G		HANDLE	5 PCS	U		WOOD FOOT	5 PCS
H		TAPPING SCREW M8 X 12MM	18 PCS	V		SCREW M4 X 38MM	4 PCS
I		HANGING RAIL SUPPORT	2 PCS	W		ALLEN KEY	1 PC
J		HANGING RAIL	1 PC	X		ANTI - TIP STRAP	2 PCS
K		PLASTIC H STRIP	3 PCS	Y		SCREW M4 X 16MM	2 PCS
L		SHELF SUPPORT	12 PCS				
M		PVC STOPPER	3 PCS				
N		HINGES 7/8	9 PCS				



(SCREWDRIVER NOT PROVIDED)

USE A FLAT HEAD SCREWDRIVER TO TIGHTEN THE CAM NUTS. A QUARTER TURN CLOCKWISE IS ALL THAT IS NEEDED.



STEP 1 - PUSH CAM BOLT INTO INSERT.

STEP 2 - ALIGN THE CAM BOLT WITH THE HOLE AND PUSH TOGETHER UNTIL FLUSH. ( MAKE SURE THE ARROW OF THE CAM LOCK IS POINTING TOWARD THE EDGE OF THE PANEL.)


STEP 3 - THE HEAD OF THE BOLT GOES INTO THE WIDE MOUTH OF THE CAM LOCK. YOU THEN TURN THE LOCK SO THE NARROW PART CLOSES OVER THE BOLT.

# STEP 1

PARTS REQUIRED

1 - CENTRE PANEL x1




HARDWARE REQUIRED

D  01

L  06

M  01

TOOLS REQUIRED



# STEP 2


PARTS REQUIRED


1 - CENTRE PANEL x1

HARDWARE REQUIRED




A  04

I  01

O  02

S  10

TOOLS REQUIRED








# STEP 3



**PARTS REQUIRED**

3 - SIDE PANEL - LEFT	x1
4 - SIDE PANEL - RIGHT	x1

**HARDWARE REQUIRED**

A		08
I		01
L		06
O		02
S		10

**TOOLS REQUIRED**






# STEP 4



**PARTS REQUIRED**

2 - LARGE SHELF PANEL	x1
5 - TOP PANEL	x1

**HARDWARE REQUIRED**

A		04
D		02
M		02

**TOOLS REQUIRED**




# STEP 5


**PARTS REQUIRED**

- 1 - CENTRE PANEL x1
- 2 - LARGE SHELF PANEL x1
- 3 - SIDE PANEL - LEFT x1

**HARDWARE REQUIRED**

- B  04


**TOOLS REQUIRED**



# STEP 6

**PARTS REQUIRED**


- 4 - SIDE PANEL - RIGHT x1
- 5 - TOP PANEL x1



**HARDWARE REQUIRED**

- C  06


**TOOLS REQUIRED**




# STEP 7

PARTS REQUIRED



6 - BOTTOM PANEL x1



HARDWARE REQUIRED


C  06

TOOLS REQUIRED




# STEP 8

PARTS REQUIRED






HARDWARE REQUIRED

F  20

U  05

TOOLS REQUIRED




# STEP 9


**PARTS REQUIRED**

7 - BACK PANEL 1 x2

8 - BACK PANEL 2 x2





**HARDWARE REQUIRED**

E  52

K  03

**TOOLS REQUIRED**



# STEP 10

**PARTS REQUIRED**

9 - DRAWER BACK x2

10 - DRAWER SIDE-LEFT x2


11 - DRAWER SIDE-RIGHT x2

12 - DRAWER FRONT x2



**HARDWARE REQUIRED**

A  16

T  06

V  04

**TOOLS REQUIRED**






# STEP 11

## PARTS REQUIRED

13 - DRAWER BASE x2



## HARDWARE REQUIRED



G 02

R 02

S 16

T 04


## TOOLS REQUIRED



# STEP 12

## PARTS REQUIRED

14 - DRAWER BOTTOM SUPPORT RAIL x2



## HARDWARE REQUIRED



D 12

P 04

Q 04




T 02

## TOOLS REQUIRED




# STEP 13

## PARTS REQUIRED



## HARDWARE REQUIRED

## TOOLS REQUIRED



# STEP 14


## PARTS REQUIRED

15 - SMALL DOOR 1 x1

16 - SMALL DOOR 2 x1



17 - LARGE DOOR MIRROR x1

## HARDWARE REQUIRED

D  18

N  09


## TOOLS REQUIRED



# STEP 15

**PARTS REQUIRED**


18 - SMALL SHELF PANEL x3



**HARDWARE REQUIRED**

J 01

**TOOLS REQUIRED**




# STEP 16

**PARTS REQUIRED**

15 - SMALL DOOR 1 x1

16 - SMALL DOOR 2 x1

17 - LARGE DOOR MIRROR x1





**HARDWARE REQUIRED**

H 18

G 03

R 03

**TOOLS REQUIRED**





1. VERTICAL ADJUSTMENT VIA SLOT IN THE MOUNTING PLATE

2. LATERAL ADJUSTMENT BY SCREW ADJUSTING

3. FRONT-TO-BACK BY THE SLACKING THE HINGE ARM MOUNTING SCREW

YOU SHOULD RE-ADJUST SCREWS AS SHOWN TO ALIGN DOOR ONCE HINGES HAVE BEEN ATTACHED.

**STEP 17**PART REQUIREDHARDWARE REQUIREDTOOLS REQUIRED**WARNING**

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.

