


FELIX 3 DRAWER CHEST ASSEMBLY INSTRUCTIONS



FOR DOMESTIC USE ONLY IMPORTANT

PLEASE READ BEFORE YOU CONTINUE FURTHER

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING

ASSEMBLE ON A SOFT CLEAN SURFACE

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTING KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES, IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE. DO NOT OVERTIGHTEN FIXINGS.






FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET). DO NOT USE POLISH, DETERGENT OR CHEMICAL CLEANERS.

THE SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.




Part Number	Part Code	Part Description	Quantity	Carton
1	S100-102-112-TA1-01	Right Side Panel	1	1/1
2	S100-102-112-TA1-02	Left Side Panel	1	1/1
3	S100-102-112-TA1-03	Top Panel	1	1/1
4	S100-102-112-TA1-04	Bottom Support Panel	2	1/1
5	S100-102-112-TA1-05	Back Support Panel	1	1/1
6	S100-102-112-TA1-06	Front Support Panel	2	1/1
7	S100-102-112-TA1-07	Top Support Panel	1	1/1
8	S100-102-112-TA1-08	Top Drawer Front	1	1/1
9	S100-102-112-TA1-09	Centre Drawer Front	1	1/1
10	S100-102-112-TA1-10	Bottom Drawer Front	1	1/1
11	S100-102-112-TA1-11	Right Drawer Side	3	1/1
12	S100-102-112-TA1-12	Left Drawer Side	3	1/1
13	S100-102-112-TA1-13	Drawer Back	3	1/1
14	S100-102-112-TA1-14	Drawer Base	3	1/1
15	S100-102-112-TA1-15	Drawer Support	3	1/1
16	S100-102-112-TA1-16	Back Panel	2	1/1

HARDWARE LIST


No.	Part Name		Qty
A	Wooden Dowel (6x25mm)		28
B	45mm Screw (4x45mm)		10
C	16mm Screw (3.5x14mm)		34
D	38mm Screw (4x38mm)		15
E	Cam Bolt (8032T)		13
F	Cam Nut (1510)		13
G	Handle (AL96mm)		3
H	Handle Screw		6
I	PVC L-Bracket		1
J	Plastic Foot		4
K	Nail		20
L	Screw Cover (Sticker 12mm)		10
M	Wall Fixings (4x20mm=1pc)		1
N	14" Drawer Slide (0.9mm)		3

TIPS FOR FITTING CAM-LOCKS

WHEN FITTING THE CAM-LOCK
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING CAM BOLT
TURN CLOCKWISE UNTIL SECURE




CORRECT **WRONG**



CAMBOLT

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)

Cam bolt head needs to be in centre



Panel Panel

Shoulder

STEP 1

PARTS REQUIRED

4 - BOTTOM SUPPORT PANEL x1

5 - BACK SUPPORT PANEL x1


6 - FRONT SUPPORT PANEL x1

7 - TOP SUPPORT PANEL x1

HARDWARE REQUIRED

A  12

TOOLS REQUIRED




STEP 2

PARTS REQUIRED

1 - RIGHT SIDE PANEL x1

2 - LEFT SIDE PANEL x1

HARDWARE REQUIRED

A  04




C  12

F  04


J  04

N  06

TOOLS REQUIRED



To Assemble the Drawer Slide, Please Follow Step as Below



STEP 3


PARTS REQUIRED

3 - TOP PANEL x1



HARDWARE REQUIRED

C  02

E  04

I  01

TOOLS REQUIRED



STEP 4

PARTS REQUIRED

2 - LEFT SIDE PANEL x1

4 - BOTTOM SUPPORT PANEL x2


5 - BACK SUPPORT PANEL x1

6 - FRONT SUPPORT PANEL x2



7 - TOP SUPPORT PANEL x1

HARDWARE REQUIRED

B  05

L  05


TOOLS REQUIRED



STEP 5


PARTS REQUIRED

1 - RIGHT SIDE PANEL x1






HARDWARE REQUIRED

B  05

L  05


TOOLS REQUIRED




STEP 6

PARTS REQUIRED




3 - TOP PANEL x1



HARDWARE REQUIRED

C  02


TOOLS REQUIRED



STEP 7


PARTS REQUIRED

16 - BACK PANEL x2





HARDWARE REQUIRED

C  06

K  22

TOOLS REQUIRED



STEP 8

PARTS REQUIRED

8 - TOP DRAWER FRONT x1

9 - CENTRE DRAWER FRONT x1


10 - BOTTOM DRAWER FRONT x1

11 - RIGHT DRAWER SIDE x3

12 - LEFT DRAWER SIDE x3

15 - DRAWER SUPPORT x3




HARDWARE REQUIRED

A  12

E  09

F  09

TOOLS REQUIRED



STEP 9



PARTS REQUIRED

- 11 - RIGHT DRAWER SIDE x3
- 12 - LEFT DRAWER SIDE x3
- 13 - DRAWER BACK x3
- 14 - DRAWER BASE x3
- 15 - DRAWER SUPPORT x3

HARDWARE REQUIRED




TOOLS REQUIRED



STEP 10




PARTS REQUIRED

- 8 - TOP DRAWER FRONT x1
- 9 - CENTRE DRAWER FRONT x1
- 10 - BOTTOM DRAWER FRONT x1




HARDWARE REQUIRED

TOOLS REQUIRED





STEP 11



PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED





STEP 12



PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED




STEP 13

PARTS REQUIRED



HARDWARE REQUIRED


TOOLS REQUIRED



FINISH

STEP 14


PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED



WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.

