


55041 HV

3201 HV

WHITE TOLEDO 3+2 DRAWER CHEST ASSEMBLY INSTRUCTIONS




IMPORTANT FOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

























- After unpacking this product please keep the original packaging in case it needs to be returned for any reason.
- Please ensure all fittings and parts are present before commencing with assembly.
 - Never drag or push products as this could cause damage to the joints making it inferior.
 - We strongly recommend that you keep children away from your work area.
 - We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
 - Assemble this product as close to its final position as possible.
 - Do not place this product next to a radiator or in direct sunlight.
 - Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
 - Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
 - Make sure any spillage is wiped off immediately.
 - Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
 - For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
 - From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
 - Do not place on a wet or damp floor as staining may occur to your floor.

***Please Note:***


The below parts have been stamped with the part number to help identify them during assembly.

Part Number	Part Code	Part Description	Quantity	Carton
1	S100-102-139-HV1-01	Top Panel	1	1/2
2	S100-102-139-HV1-02	Right Side Panel	1	2/2
3	S100-102-139-HV1-03	Left Side Panel	1	2/2
4	S100-102-139-HV1-04	Back Crossbeam	2	1/2
5	S100-102-139-HV1-05	Side Plinth	2	1/2
6	S100-102-139-HV1-06	Front Plinth	1	1/2
7	S100-102-139-HV1-07	Support	1	1/2
8	S100-102-139-HV1-08	Drawer Side	8	1/2
9	S100-102-139-HV1-09	Large Drawer Side	2	1/2
10	S100-102-139-HV1-10	Small Drawer Back	2	1/2
11	S100-102-139-HV1-11	Medium Drawer Back	2	1/2
12	S100-102-139-HV1-12	Large Drawer Back	1	1/2
13	S100-102-139-HV1-13	Back Panel	2	2/2
14	S100-102-139-HV1-14	Front Frame	1	2/2
15	S100-102-139-HV1-15	Large Drawer Front	1	2/2
16	S100-102-139-HV1-16	Medium Drawer Front	2	2/2
17	S100-102-139-HV1-17	Small Drawer Front	2	2/2
18	S100-102-139-HV1-18	Central Drawer Runner Support	1	1/2
19	S100-102-140-HV1-19	Small Drawer Bottom	2	2/2
20	S100-102-140-HV1-20	Large Drawer Bottom	3	2/2
21	S100-102-140-HV1-21	Drawer Support	3	1/2

FITTINGS LIST


A x 30  +/2 Cam Bolt 32xØ6mm	B x 30  +/2 Can Nut Ø15 mm	C x 74  +/2 Dowel Ø8 x 30 mm	D x 2  +/1 Washer Ø16x7 mm	E x 18  Drawer Spacer 52x45x22 mm
F x 1  Anti-tip Strap 200x20x1 mm	G x 30  +/2 Screw Ø4 x 14 mm	H x 12  +/2 Screw Ø4 x 40 mm	I x 8  +/1 Screw Ø3.5 x 40 mm	J x 7  +/1 Screw Ø4 x 25 mm
K x 4  +/1 Plastic Foot L 19x17x8mm Ø2mm	L x 38  +/2 Nail 10x10 Ringed - 1,5x23mm	M x 3  Glue 10g	N x 12  +/2 Hole Plugs 19mm	O x 36  +/2 Screw Ø4 x 22 mm
P x 14  +/2 Screw Ø3,5 x 14 mm	Q x 18  +/2 Screw Ø3 x 16 mm	R x 1  +/1 Screw Ø3,5 x 30 mm	S x 18  +/2 Triangle Support Angle	T x 8  HANDLE WITH SCREWS
U x 5  Normal Slides 350mm	V x 1  Perfil H 885mm	W x 22  +/2 Screw Ø3 x 20 mm	X x 4  +/1 "L" Metalic Support 18 x 18mm	

TOOLS REQUIRED




TIPS FOR FITTINGS CAM-LOCKS


WHEN FITTING CAM NUT, ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE



↑
CORRECT




WRONG



Cam bolt head needs to be in centre

CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)




STEP 1


PARTS REQUIRED

2 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED




C  06

K  02


L  02

M  01

TOOLS REQUIRED



Detail 1




Detail 2

STEP 2


PARTS REQUIRED

2 - RIGHT SIDE PANEL x1




HARDWARE REQUIRED

A  02


E  09

O  18


TOOLS REQUIRED



Detail 3



Detail 4




STEP 3

PARTS REQUIRED



2 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED


G  09

U  RIGHT 04

TOOLS REQUIRED



PRE-DRILLED HOLE



SECOND HOLE (LINE UP WITH PRE-DRILLED HOLE)

STEP 4


PARTS REQUIRED

3 - LEFT SIDE PANEL x1

HARDWARE REQUIRED




C  06

K  02


L  02

M  01

TOOLS REQUIRED



Detail 1




Detail 2


STEP 5

PARTS REQUIRED

3 - LEFT SIDE PANEL x1



HARDWARE REQUIRED

A  02


E  09

O  18


TOOLS REQUIRED




PLEASE NOTE
PRE-DRILLED HOLES



Detail 3



Detail 4




STEP 6

PARTS REQUIRED


3 - LEFT SIDE PANEL x1

HARDWARE REQUIRED


G  09

U  LEFT 04

TOOLS REQUIRED



PRE-DRILLED HOLE







SECOND HOLE (LINE UP WITH PRE-DRILLED HOLE)

STEP 7





PARTS REQUIRED

4 - BACK CROSSBEAM	x2
6 - FRONT PLINTH	x1
7 - SUPPORT	x1
18 -CENTRAL DRAWER RUNNER SUPPORT X1	

HARDWARE REQUIRED

C		16
G		02
M		01
X		02

TOOLS REQUIRED





STEP 8



PARTS REQUIRED

18 -CENTRAL DRAWER RUNNER SUPPORT X1	
--------------------------------------	--

HARDWARE REQUIRED

G		04
U		01

TOOLS REQUIRED




STEP 9

PARTS REQUIRED

14 - FRONT FRAME x1




HARDWARE REQUIRED

A  08



G  02

X  02

TOOLS REQUIRED



Detail 3



Detail 16

STEP 10

PARTS REQUIRED




2 - RIGHT SIDE PANEL x1

14 - FRONT FRAME x1


HARDWARE REQUIRED

B  04

TOOLS REQUIRED




Detail 5



STEP 11

PARTS REQUIRED




3 - LEFT SIDE PANEL x1




HARDWARE REQUIRED

B  04

TOOLS REQUIRED



Detail 5




Cam bolt head needs to be in centre

STEP 12

PARTS REQUIRED




4 - BACK CROSSBEAM x2




HARDWARE REQUIRED

B  04

TOOLS REQUIRED



Detail 5




Cam bolt head needs to be in centre

STEP 13




PARTS REQUIRED

1 - TOP PANEL x1

HARDWARE REQUIRED

A  06


TOOLS REQUIRED



STEP 14

PARTS REQUIRED

1 - TOP PANEL x1







HARDWARE REQUIRED

B  04

G  02

TOOLS REQUIRED



STEP 15

PARTS REQUIRED




7 - SUPPORT x1

18 - CENTRAL DRAWER RUNNER SUPPORT X1

HARDWARE REQUIRED

G  01


TOOLS REQUIRED



Detail 16

STEP 16

PARTS REQUIRED






HARDWARE REQUIRED


B  02

G  01


TOOLS REQUIRED



Detail 16




Detail 5



STEP 17




PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED




Detail 17

STEP 18


PARTS REQUIRED

5 - SIDE PLINTH x2




6 - FRONT PLINTH x1



HARDWARE REQUIRED



TOOLS REQUIRED




Detail 7


STEP 19

PARTS REQUIRED

13 - BACK PANEL x2





HARDWARE REQUIRED


V  01

TOOLS REQUIRED

* For your future reference
Order number should be here




Detail 8





STEP 20

PARTS REQUIRED






HARDWARE REQUIRED

P  14


Q  18

S  18


TOOLS REQUIRED



Detail 9



Detail 10





STEP 21



PARTS REQUIRED

8 - DRAWER SIDE	x8
9 - LARGE DRAWER SIDE	x2
21 - DRAWER SUPPORT	x3

HARDWARE REQUIRED

C		26
M		01

TOOLS REQUIRED





STEP 22



PARTS REQUIRED

10 - SMALL DRAWER BACK	x2
11 - MEDIUM DRAWER BACK	x2
12 - LARGE DRAWER BACK	x1

HARDWARE REQUIRED

C		20
M		01

TOOLS REQUIRED




STEP 23



PARTS REQUIRED

- 15- LARGE DRAWER FRONT x1
- 16- MEDIUM DRAWER FRONT x2
- 17- SMALL DRAWER FRONT x2

HARDWARE REQUIRED

- A  12

TOOLS REQUIRED




STEP 24



PARTS REQUIRED

- 8 - DRAWER SIDE x4
- 10 - SMALL DRAWER BACK x2

HARDWARE REQUIRED

- H  04


TOOLS REQUIRED



STEP 25

PARTS REQUIRED




17- SMALL DRAWER FRONT x2



HARDWARE REQUIRED

B  04


TOOLS REQUIRED



STEP 26

PARTS REQUIRED





19- SMALL DRAWER BOTTOM x2



HARDWARE REQUIRED


L  10

TOOLS REQUIRED




STEP 27




PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED




STEP 28




PARTS REQUIRED




HARDWARE REQUIRED



TOOLS REQUIRED



Detail 13



Detail 14

STEP 29

PARTS REQUIRED



8 - DRAWER SIDE x4

11- MEDIUM DRAWER BACK x2

HARDWARE REQUIRED

H  04


TOOLS REQUIRED



STEP 30

PARTS REQUIRED



16- MEDIUM DRAWER FRONT x2



HARDWARE REQUIRED

B  04

TOOLS REQUIRED




STEP 31

PARTS REQUIRED

20- LARGE DRAWER BOTTOM x2





21- DRAWER SUPPORT x2



HARDWARE REQUIRED


L  16

TOOLS REQUIRED




STEP 32

PARTS REQUIRED






HARDWARE REQUIRED

I  04


U  02

W  08

TOOLS REQUIRED




Detail 15




STEP 33




PARTS REQUIRED




HARDWARE REQUIRED



TOOLS REQUIRED



Detail 13



Detail 14

STEP 34




PARTS REQUIRED

- 9 - LARGE DRAWER SIDE x2
- 12- LARGE DRAWER BACK x1

HARDWARE REQUIRED



TOOLS REQUIRED




Detail 11

STEP 35

PARTS REQUIRED



15- LARGE DRAWER FRONT x1



HARDWARE REQUIRED

B  04

TOOLS REQUIRED




STEP 36


PARTS REQUIRED

20- LARGE DRAWER BOTTOM x1



21- DRAWER SUPPORT x1



HARDWARE REQUIRED


L  08

TOOLS REQUIRED





STEP 37




PARTS REQUIRED




HARDWARE REQUIRED



TOOLS REQUIRED




Detail 15




STEP 38




PARTS REQUIRED




HARDWARE REQUIRED



TOOLS REQUIRED





Detail 13



Detail 14

STEP 39


PARTS REQUIRED



TIP
If desired, after assembly use an alcohol cleaner to erase the number printed on the parts.


HARDWARE REQUIRED

TOOLS REQUIRED



STEP 40


PARTS REQUIRED



HARDWARE REQUIRED

D		02
F		01
R		01

TOOLS REQUIRED



WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.

