

# GREY/CHARCOAL CONCRETE EFFECT NORDIC MERCHANT CHEST ASSEMBLY INSTRUCTIONS



FOR DOMESTIC USE ONLY  
IMPORTANT

PLEASE READ BEFORE YOU CONTINUE FURTHER

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTING KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES, IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE. DO NOT OVERTIGHTEN FIXINGS.

FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET). DO NOT USE POLISH, DETERGENT OR CHEMICAL CLEANERS.
















THE SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.



## PART LIST


Part Number	Part Code	Part Description	Quantity	Carton
1	S100-102-156-TA1-01	Right Side Panel	1	1/2
2	S100-102-156-TA1-02	Left Side Panel	1	1/2
3	S100-102-156-TA1-03	Bottom Centre Panel	1	1/2
4	S100-102-156-TA1-04	Top Centre Panel (L)	1	1/2
5	S100-102-156-TA1-05	Top Centre Panel (R)	1	1/2
6	S100-102-156-TA1-06	Top Panel	1	1/2
7	S100-102-156-TA1-07	Bottom Panel	1	1/2
8	S100-102-156-TA1-08	Right Drawer Side	7	2/2
9	S100-102-156-TA1-09	Left Drawer Side	7	2/2
10	S100-102-156-TA1-10	Large Front Support Panel	1	1/2
11	S100-102-156-TA1-11	Large Back Support Panel	1	1/2
12	S100-102-156-TA1-12	Small Front Support Panel (L)	1	1/2
13	S100-102-156-TA1-13	Small Front Support Panel (R)	1	1/2
14	S100-102-156-TA1-14	Large Drawer Back	4	2/2
15	S100-102-156-TA1-15	Small Drawer Back	3	2/2
16	S100-102-156-TA1-16	Drawer Support	4	2/2
17	S100-102-156-TA1-17	Top Support	3	2/2
18	S100-102-156-TA1-18	Small Drawer Front (L)	1	1/2
19	S100-102-156-TA1-19	Top Large Drawer Front (R)	1	2/2
20	S100-102-156-TA1-20	Small Drawer Front (Centre)	1	1/2
21	S100-102-156-TA1-21	Bottom Large Drawer Front (L)	1	2/2
22	S100-102-156-TA1-22	Small Drawer Front (R)	1	1/2
23	S100-102-156-TA1-23	Top Large Drawer Front (L)	1	2/2
24	S100-102-156-TA1-24	Bottom Large Drawer Front (R)	1	2/2
25	S100-102-156-TA1-25	Back Panel	2	1/2
26	S100-102-156-TA1-26	Large Drawer Base	4	1/2
27	S100-102-156-TA1-27	Small Drawer Base	3	1/2

# HARDWARE LIST


No.	Part Name		Qty	Carton
A	Wooden Dowel (6x25mm)		x60	2
B	45mm Screw (4x45mm)		x16	2
C	14mm Screw (3.5x14mm)		x88	2
D	38mm Screw (4x38mm)		x32	2
E	Cam Bolt (8032T)		x26	2
F	Cam Nut (1512)		x26	2
G	Wood Leg + Plastic Foot		x5	2
H	6/8" Nail		x80	2
I	14" Drawer Slide		x7	1
J	PVC L-Bracket		x3	2
K	Handle+Screw (3x16mm=8pcs)		x3	2
L	Screw Cover (CB-White)		x4	2
M	Handle+Screw (T-4538 (4x20mm=2pcs))		x2	2
N	Handle+Screw (Y-8238 (3x16mm=2pcs))		x2	2
O	Wall Fixings (4x20mm=1pc)		x1	2

## TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT, ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE




**CORRECT**      **WRONG**



Cam bolt head needs to be in centre

### CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example below)



Shoulder

Panel

Panel

# STEP 1


## PARTS REQUIRED


3 - BOTTOM CENTRE PANEL x1


4 - TOP CENTRE PANEL(L) x1

5 - TOP CENTRE PANEL(R) x1








## HARDWARE REQUIRED

A  06

C  3.5x14mm 08

I  04

## TOOLS REQUIRED



# STEP 2


## PARTS REQUIRED

3 - BOTTOM CENTRE PANEL x1

4 - TOP CENTRE PANEL (L) x1

5 - TOP CENTRE PANEL (R) x1



## HARDWARE REQUIRED

C  3.5x14mm 08

F  04

I  04

## TOOLS REQUIRED



# STEP 3

## PARTS REQUIRED

10 - LARGE FRONT SUPPORT PANEL x1


11 - LARGE BACK SUPPORT PANEL x1

12 - SMALL FRONT SUPPORT PANEL(L)x1


13 - SMALL FRONT SUPPORT PANEL(R)x1

17 - TOP SUPPORT x3

## HARDWARE REQUIRED

A  18

## TOOLS REQUIRED



# STEP 4

## PARTS REQUIRED

4 - TOP CENTRE PANEL(L) x1

5 - TOP CENTRE PANEL (R) x1

10 -LARGE FRONT SUPPORT PANEL x1



11 -LARGE BACK SUPPORT PANEL x1

17 -TOP SUPPORT x1


## HARDWARE REQUIRED

B  4x45mm 04


## TOOLS REQUIRED



1st




2nd



# STEP 5

## PARTS REQUIRED



3 - BOTTOM CENTRE PANEL x1



## HARDWARE REQUIRED

B  02

## TOOLS REQUIRED




# STEP 6

## PARTS REQUIRED

1 - RIGHT SIDE PANEL x1

## HARDWARE REQUIRED




A  04

C  06

F  02

I  03

## TOOLS REQUIRED




# STEP 7

## PARTS REQUIRED


1 - RIGHT SIDE PANEL x1

13 - SMALL FRONT SUPPORT PANEL(R)x1



17 - TOP SUPPORT x1



## HARDWARE REQUIRED

B  02

## TOOLS REQUIRED




# STEP 8

## PARTS REQUIRED

2 - LEFT SIDE PANEL x1

## HARDWARE REQUIRED



A  04

C  06


F  02

I  03

## TOOLS REQUIRED



**To Assemble the Drawer Slide, Please Follow Step as Below**




# STEP 9

## PARTS REQUIRED


2 - LEFT SIDE PANEL x1

12 - SMALL FRONT SUPPORT PANEL(L) x1



17 - TOP SUPPORT x1



## HARDWARE REQUIRED

B  4x45mm 02

## TOOLS REQUIRED




# STEP 10

## PARTS REQUIRED

6 - TOP PANEL x1



## HARDWARE REQUIRED

C  3.5x14mm 06

E  08

J  03

## TOOLS REQUIRED






# STEP 11


## PARTS REQUIRED

6 - TOP PANEL x1



7 - BOTTOM PANEL x1



## HARDWARE REQUIRED


B  06

## TOOLS REQUIRED




# STEP 12

## PARTS REQUIRED





## HARDWARE REQUIRED

C  26

G  05


## TOOLS REQUIRED



# STEP 13

## PARTS REQUIRED



25 - BACK PANEL x2



## HARDWARE REQUIRED

H  80

## TOOLS REQUIRED



# STEP 14

## PARTS REQUIRED

19 - TOP LARGE DRAWER FRONT(R) x1

21 - BOTTOM LARGE DRAWER FRONT(L) x1



23 - TOP LARGE DRAWER FRONT(L) x1

24 - BOTTOM LARGE DRAWER FRONT(R) x1

## HARDWARE REQUIRED

E  12

## TOOLS REQUIRED



# STEP 15


## PARTS REQUIRED

8 - RIGHT DRAWER SIDE x7

9 - LEFT DRAWER SIDE x7



16 -DRAWER SUPPORT x4

## HARDWARE REQUIRED

A  28

F  18

## TOOLS REQUIRED



# STEP 16

## PARTS REQUIRED

8 - RIGHT DRAWER SIDE x4

9 - LEFT DRAWER SIDE x4

14 -LARGE DRAWER BACK x4



16 -DRAWER SUPPORT x4

26 -LARGE DRAWER BASE x4

## HARDWARE REQUIRED

D  4x38mm 20

## TOOLS REQUIRED



# STEP 17


## PARTS REQUIRED

19 - TOP LARGE DRAWER FRONT(R) x1

21 - BOTTOM LARGE DRAWER FRONT(L)x1


23 - TOP LARGE DRAWER FRONT(L) x1

24 - BOTTOM LARGE DRAWER FRONT(R)x1





## HARDWARE REQUIRED

## TOOLS REQUIRED




x4




# STEP 18

## PARTS REQUIRED





## HARDWARE REQUIRED

K  02

M  01


N  01

## TOOLS REQUIRED





# STEP 19



## PARTS REQUIRED



## HARDWARE REQUIRED



## TOOLS REQUIRED




# STEP 20



## PARTS REQUIRED



## HARDWARE REQUIRED



## TOOLS REQUIRED




# STEP 21

## PARTS REQUIRED

18 - SMALL DRAWER FRONT(L) x1

20 - SMALL DRAWER FRONT CENTRE x1

22 - SMALL DRAWER FRONT(R) x1





x3

## HARDWARE REQUIRED

F  06


## TOOLS REQUIRED



**When Fitting Cams**  
Ensure starting position correct before you insert connecting bolt turn clockwise until secure.

# STEP 22

## PARTS REQUIRED





## HARDWARE REQUIRED

K  01

M  01


N  01

## TOOLS REQUIRED





# STEP 23



**PARTS REQUIRED**



**HARDWARE REQUIRED**



C		12
I		06

**TOOLS REQUIRED**




# STEP 24

**PARTS REQUIRED**





# STEP 25

**PARTS REQUIRED**




**HARDWARE REQUIRED**



# STEP 26


**PARTS REQUIRED**



**HARDWARE REQUIRED**



**TOOLS REQUIRED**



## WARNING

**Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.**

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.

