


NEVADA SLIDING DOOR BEDSIDE ASSEMBLY INSTRUCTIONS



IMPORTANT FOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE



After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat.

Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.

- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.

TOOLS REQUIRED






















PARTS LIST

Please Note:

The below parts have all been stamped with the part number to help identify them during assembly.


Part Number	Part Description	Quantity	Carton
1	Top Panel	1	1/1
2	Right Side Panel	1	1/1
3	Left Side Panel	1	1/1
4	Shelf	1	1/1
5	Sliding Door	1	1/1
6	Back Panel	1	1/1
7	Drawer Side	2	1/1
8	Drawer Front	1	1/1
9	Drawer Back Panel	1	1/1
10	Drawer Botom	1	1/1
11	Front Baseboard	1	1/1

FITTINGS LIST

<p>A</p>  <p>Flat Head Screw Ø6,0 x 10mm (4x)</p> <p>1/+</p>	<p>B</p>  <p>Flat Head Screw Ø4,0 x 14mm (6x)</p> <p>1/+</p>	<p>C</p>  <p>Flan Head Screw Ø4,0 x 20mm (4x)</p> <p>1/+</p>	
<p>D</p>  <p>Flat Head Screw Ø4,0 x 50mm (8x)</p> <p>2/+</p>	<p>E</p>  <p>2/+ Dowel Ø6,0 x 30mm (20x)</p>	<p>F</p>  <p>2/+ Nail 10 x 10 (22x)</p>	
<p>G</p>  <p>1/+ Cam Bolt (6x)</p>	<p>H</p>  <p>1/+ Cam Nut Ø12mm (2x)</p>	<p>I</p>  <p>1/+ Plastic Foot (4x)</p>	<p>J</p>  <p>2/+ Hole Plugs (12x)</p>
<p>K</p>  <p>Glue (1x)</p>	<p>L</p>  <p>Handle (2x)</p>	<p>M</p>  <p>1/+ Cam Nut Ø15mm (4x)</p>	<p>N</p>  <p>Spring top guide(2x)</p>
<p>O</p>  <p>Sliding Door Castor(2x)</p>	<p>P</p>  <p>2/+ Flan Head Screw Ø4,0 x 14mm (12x)</p>	<p>Q</p>  <p>Drawer Runners (1x)</p>	<p>R</p>  <p>Plastic Rail (2x)</p>
<p>S</p>  <p>2/+ Hole Plugs (2x)</p>			


TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT. ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE




↑

CORRECT



↑




WRONG



Cam bolt head needs to be in centre

CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)






STEP 1




PARTS REQUIRED

3 - LEFT SIDE PANEL x1

HARDWARE REQUIRED

E		02
F		02
I		02
K	GLUE	01

TOOLS REQUIRED






STEP 2





PARTS REQUIRED

3 - LEFT SIDE PANEL x1

HARDWARE REQUIRED

A		02
B		01
Q	LEFT 	01

TOOLS REQUIRED







STEP 3



PARTS REQUIRED

2 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED

E		02
F		02
I		02
K		01

TOOLS REQUIRED






STEP 4



PARTS REQUIRED

2 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED

A		02
B		01
Q		01

TOOLS REQUIRED




STEP 5




PARTS REQUIRED

1 - TOP PANEL x1

HARDWARE REQUIRED

G  04

TOOLS REQUIRED




STEP 6




PARTS REQUIRED

4 - SHELF x1

HARDWARE REQUIRED

R  01

TOOLS REQUIRED



Detail 15


STEP 7

PARTS REQUIRED

4 - SHELF x1



11 - FRONT BASEBORD x1

HARDWARE REQUIRED

E  08
Ø6,0 x 30mm

K  01

TOOLS REQUIRED



STEP 8

PARTS REQUIRED


2 - RIGHT SIDE PANEL x1

3 - LEFT SIDE PANEL x1

4 - SHELF x1



11 - FRONT BASEBORD x1

HARDWARE REQUIRED

D  06
Ø4,0 x 50mm

K  01

TOOLS REQUIRED




STEP 9

SEC/SH/12/21/CA1

PARTS REQUIRED

1 - TOP PANEL x1





HARDWARE REQUIRED


M  04

K  01


TOOLS REQUIRED



Detail 1




Detail 7



STEP 10

SEC/AY/12/21/CA1




PARTS REQUIRED



HARDWARE REQUIRED

R  01

TOOLS REQUIRED






Detail 15

STEP 11



PARTS REQUIRED

5 - SLIDING DOOR x1

HARDWARE REQUIRED


- N  02
- O  02
- P  12
Ø4.0 x 14mm

TOOLS REQUIRED





STEP 12



PARTS REQUIRED



HARDWARE REQUIRED



- C  02
Ø4.0 x 20mm
- L  01

TOOLS REQUIRED




STEP 13

PARTS REQUIRED






HARDWARE REQUIRED

TOOLS REQUIRED



BEFORE PLACING THE DOOR
KEEP THE TOP GUIDE LOCKED

UNLOCK THE GUIDE
WHEN IT IS
ON THE RAIL



Detail 14

Detail 13


STEP 14

PARTS REQUIRED

7 - DRAWER SIDE x2



9 - DRAWER BACK PANEL x1

HARDWARE REQUIRED

E  08
Ø6,0 x 30mm

K  01
GLUE

TOOLS REQUIRED




Detail 1

STEP 15




PARTS REQUIRED

8 - DRAWER FRONT x1

HARDWARE REQUIRED

G  02

TOOLS REQUIRED




STEP 16

PARTS REQUIRED




7 - DRAWER SIDE x2

9 - DRAWER BACK PANEL x1

HARDWARE REQUIRED

D  02
Ø4,0 x 50mm


TOOLS REQUIRED



STEP 17

PARTS REQUIRED

8 - DRAWER FRONT x1








HARDWARE REQUIRED

H  02

K  GLUE 01


TOOLS REQUIRED




STEP 18

PARTS REQUIRED









10 - DRAWER BOTTOM x1



HARDWARE REQUIRED


F  10 x 10 04

TOOLS REQUIRED




STEP 19





PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED




Detail 10

STEP 20





PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED





STEP 21




PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED




Detail 11

STEP 22



PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED




Detail 12


STEP 23

PARTS REQUIRED



6 - BACK PANEL x1



HARDWARE REQUIRED


F  14
10 x 10

TOOLS REQUIRED





Detail 8

Detail 8





* For your future reference
Order Number should be here



Detail 8

STEP 24

PARTS REQUIRED




HARDWARE REQUIRED

J  10


Detail 12

Detail 12

Detail 12



Detail 12



TIP

If desired, after assembly
use an alcohol cleaner
to erase the number
printed on the parts.

