



NEVADA VANITY DRESSING TABLE SET

ASSEMBLY INSTRUCTIONS

3D EFFECT GREY



* You should assemble this product with two people




IMPORTANT FOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.

























PARTS LIST

Please Note:
The below parts have all been stamped with the part number/color to help identify them during assembly.


| Part Number | Part Code | Part Description | Quantity | Carton |
|-------------|---------------------|-----------------------------------|----------|--------|
| 1 | S100-107-023-SP1-01 | Front Baseboard - BLUE | 1 | 1/2 |
| 2 | S100-107-023-SP1-02 | Back Baseboard - RED | 1 | 1/2 |
| 3 | S100-107-023-SP1-03 | Left Side Panel- RED | 1 | 1/2 |
| 4 | S100-107-023-SP1-04 | Base Panel - BLACK | 1 | 1/2 |
| 5 | S100-107-023-SP1-05 | Left Divison Panel - GREEN | 1 | 1/2 |
| 6 | S100-107-023-SP1-06 | Front Crossbar - BLUE | 1 | 1/2 |
| 7 | S100-107-023-SP1-07 | Back Crossbar - YELLOW | 1 | 1/2 |
| 8 | S100-107-023-SP1-08 | Right Side Panel - BLUE | 1 | 1/2 |
| 9 | S100-107-023-SP1-09 | Top Panel - RED | 1 | 1/2 |
| 10 | S100-107-023-SP1-10 | Mirror Panel - BLUE | 1 | 2/2 |
| 11 | S100-107-023-SP1-11 | Back Panel | 1 | 1/2 |
| 12 | S100-107-023-SP1-12 | Stool Side Panel - GREEN | 2 | 1/2 |
| 13 | S100-107-023-SP1-13 | Stool Crosspiece - YELLOW | 2 | 1/2 |
| 14 | S100-107-023-SP1-14 | Stool Seat | 1 | 1/2 |
| 15 | S100-107-023-SP1-15 | Shelf - RED | 1 | 1/2 |
| 16 | S100-107-023-SP1-16 | Drawer Side - BLUE | 4 | 1/2 |
| 17 | S100-107-023-SP1-17 | Large Drawer Back Panel - RED | 1 | 1/2 |
| 18 | S100-107-023-SP1-18 | Large Drawer Front | 1 | 1/2 |
| 19 | S100-107-023-SP1-19 | Large Drawer Bottom | 1 | 1/2 |
| 20 | S100-107-023-SP1-20 | Drawer Bottom Support Bar - BLACK | 1 | 1/2 |
| 21 | S100-107-023-SP1-21 | Small Drawer Back Panel - RED | 1 | 1/2 |
| 22 | S100-107-023-SP1-22 | Small Drawer Front | 1 | 1/2 |
| 23 | S100-107-023-SP1-23 | Small Drawer Bottom | 1 | 1/2 |
| 24 | S100-107-023-SP1-24 | Door | 1 | 1/2 |

FITTINGS LIST


| | | | |
|---|---|--|---|
| <p>A</p>  <p>Flan Head Screw Ø4,0 x 14mm (2x)</p> <p>1/+</p> | <p>B</p>  <p>Flat Head Screw Ø4,0 x 50mm (4x)</p> <p>1/+</p> | <p>C</p>  <p>Flat Head Screw Ø 4,0 x 45mm (27x)</p> <p>2/+</p> | |
| <p>D</p>  <p>Flat Head Screw Ø4,0 x 14mm (20x)</p> <p>2/+</p> | <p>E</p>  <p>Flat Head Screw MQ M4 x 20mm (6x)</p> <p>1/+</p> | <p>F</p>  <p>Flat Head Screw Ø6,0 x 8mm (8x)</p> <p>1/+</p> | <p>G</p>  <p>Nail 10 x 10 (40x)</p> <p>4/+</p> |
| <p>H</p>  <p>Glue (2x)</p> | <p>I</p>  <p>Drawer Runners (2x)</p> | | <p>J</p>  <p>Hinge Plate (2x)</p> |
| <p>K</p>  <p>Hinge (2x)</p> | <p>L</p>  <p>Cam Nut 12mm (14x)</p> <p>2/+</p> | <p>M</p>  <p>Cam Bolt (14x)</p> <p>2/+</p> | <p>N</p>  <p>Dowel Ø6,0 x 30mm (46x)</p> <p>2/+</p> |
| <p>O</p>  <p>Strap 200mm (2x)</p> | <p>P</p>  <p>Plastic Foot (10x)</p> <p>2/+</p> | <p>Q</p>  <p>Handle (3x)</p> | <p>R</p>  <p>Hole Plugs (24x)</p> <p>2/+</p> |
| <p>S</p>  <p>Washer (4x)</p> <p>1/+</p> | <p>T</p>  <p>Drawer Divider Kit (1x)</p> | <p>U</p>  <p>Drawer Divider Finish (12x)</p> | <p>V</p>  <p>Flat Head Screw Ø 3,5 x 30mm (1x)</p> <p>1/+</p> |

TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT, ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE




CORRECT WRONG



Cam bolt head needs to be in centre

CAMBOLT

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example beside)




STEP 1

PARTS REQUIRED


3 - LEFT SIDE PANEL (RED) x1

HARDWARE REQUIRED




D  04
Ø4,0 x 14mm

H  01

J  02

N  02
Ø6,0 x 30mm

TOOLS REQUIRED




STEP 2

PARTS REQUIRED

3 - LEFT SIDE PANEL (RED) x1

HARDWARE REQUIRED





F  02
Ø6,0 x 8mm

G  02

I  01
Left

P  02

TOOLS REQUIRED



STEP 3

PARTS REQUIRED


5- LEFT DIVISION PANEL (GREEN) x1

HARDWARE REQUIRED





F  02
Ø6,0 x 8mm

H  01


I  Right 01

N  02
Ø6,0 x 30mm

TOOLS REQUIRED



Detail 6




Detail 1

STEP 4

PARTS REQUIRED

5- LEFT DIVISION PANEL (GREEN) x1

HARDWARE REQUIRED




F  02
Ø6,0 x 8mm

G  02



I  Left 01

P  02

TOOLS REQUIRED



Detail 6



Detail 4


STEP 5

PARTS REQUIRED


8 - RIGHT SIDE PANEL (BLUE) x1


HARDWARE REQUIRED

F  02
Ø6,0 x 8mm

G  02




H  01

I  Right 01


N  02
Ø6,0 x 30mm

P  02


TOOLS REQUIRED



Detail 6



Detail 1



Detail 4

STEP 6


PARTS REQUIRED


1 - FRONT BASEBOARD (BLUE) x1

2 - BACK BASEBOARD (RED) x1



4 - BASE PANEL (BLACK) x1

HARDWARE REQUIRED

H  01

N  12
Ø6,0 x 30mm

TOOLS REQUIRED



Detail 1

STEP 7

PARTS REQUIRED


6 - FRONT CROSSBAR (BLUE) x1

7 - BACK CROSSBAR (YELLOW) x1




15 - SHELF (RED) x1

HARDWARE REQUIRED

H  01

N  Ø6,0 x 30mm 10

TOOLS REQUIRED




STEP 8




PARTS REQUIRED

9 - TOP PANEL (RED) x1

HARDWARE REQUIRED

M  06

TOOLS REQUIRED





STEP 9




PARTS REQUIRED

- 5 - LEFT DIVISION PANEL (GREEN) x1
- 6 - FRONT CROSSBAR (BLUE) x1
- 7 - BACK CROSSBAR (YELLOW) x1
- 8 - RIGHT SIDE PANEL (BLUE) x1


HARDWARE REQUIRED

- C  04
Ø4,0 x 45mm
- H  01

TOOLS REQUIRED



Detail 1



Detail 13


STEP 10

PARTS REQUIRED

4 - BASE PANEL (BLACK) x1





15 - SHELF (RED) x1

HARDWARE REQUIRED


C  03
Ø4,0 x 45mm

H  01

TOOLS REQUIRED



Detail 1



Detail 13


STEP 11

PARTS REQUIRED

1 - FRONT BASEBOARD (BLUE) x1





2 - BACK BASEBOARD (RED) x1

HARDWARE REQUIRED


C  02
Ø4,0 x 45mm

H  01

TOOLS REQUIRED



Detail 1




Detail 13


STEP 12

PARTS REQUIRED

3 - LEFT SIDE PANEL (RED) x1






HARDWARE REQUIRED


C  05
Ø4,0 x 45mm

H  01
Glue

TOOLS REQUIRED



Detail 1




Detail 13

STEP 13

PARTS REQUIRED

9 - TOP PANEL (RED) x1






HARDWARE REQUIRED


H  01

L  06


TOOLS REQUIRED



Detail 1




Detail 21




STEP 14


PARTS REQUIRED

10 - MIRROR PANEL (BLUE) x1






HARDWARE REQUIRED


C  09
Ø4,0 x 45mm

H  01


TOOLS REQUIRED



Detail 1



Detail 13




* You should assemble this product with two people

STEP 15



PARTS REQUIRED

11 - BACK PANEL x1




HARDWARE REQUIRED

G  12
10 x 10

TOOLS REQUIRED



* For your future reference Order Number should be here.



Detail 15

STEP 16

PARTS REQUIRED


16 - DRAWER SIDE (BLUE) x2

17 - LARGE DRAWER BACK PANEL (RED) x1



20 - DRAWER BOTTOM SUPPORT BAR (BLACK) x1

HARDWARE REQUIRED

H  01

N  Ø6,0 x 30mm 06

TOOLS REQUIRED




STEP 17



PARTS REQUIRED

18 - LARGE DRAWER FRONT x1

HARDWARE REQUIRED

M  02

TOOLS REQUIRED




STEP 18

PARTS REQUIRED

16 - DRAWER SIDE (BLUE) x2



17 - LARGE DRAWER BACK PANEL (RED) x1

HARDWARE REQUIRED

C  Ø4,0 x 45mm 02

H  01


TOOLS REQUIRED




STEP 19

PARTS REQUIRED



18 - LARGE DRAWER FRONT x1



HARDWARE REQUIRED


H  01

TOOLS REQUIRED





STEP 20




PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED




Detail 21


STEP 21

PARTS REQUIRED





19 - LARGE DRAWER BOTTOM x1



HARDWARE REQUIRED



TOOLS REQUIRED




Detail 22



STEP 22

PARTS REQUIRED



20 - DRAWER BOTTOM SUPPORT BAR (BLACK) X 1





HARDWARE REQUIRED



TOOLS REQUIRED




Detail 1





STEP 23


PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED




STEP 24



PARTS REQUIRED



HARDWARE REQUIRED





TOOLS REQUIRED





STEP 25

PARTS REQUIRED

HARDWARE REQUIRED




TOOLS REQUIRED




STEP 26

PARTS REQUIRED

HARDWARE REQUIRED




TOOLS REQUIRED




STEP 27


PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED



STEP 28

PARTS REQUIRED


16 - DRAWER SIDE (BLUE) x2


21 - SMALL DRAWER BACK PANEL (RED) x1

22 - SMALL DRAWER FRONT x1





HARDWARE REQUIRED

H  01

M  02

N  Ø6,0 x 30mm 04

TOOLS REQUIRED



Detail 1

Detail 9


STEP 29


PARTS REQUIRED

16 - DRAWER SIDE (BLUE) x2





21 - SMALL DRAWER BACK PANEL (RED) x1

HARDWARE REQUIRED

C  Ø4,0 x 45mm 02

H  01

TOOLS REQUIRED




Detail 1

Detail 20

STEP 30

PARTS REQUIRED

22 - SMALL DRAWER FRONT x1




HARDWARE REQUIRED

H  01

TOOLS REQUIRED




Detail 1




STEP 31

PARTS REQUIRED






HARDWARE REQUIRED


L  02

R  04

TOOLS REQUIRED




Detail 21




STEP 32

PARTS REQUIRED





23 - SMALL DRAWER BOTTOM x1







HARDWARE REQUIRED



TOOLS REQUIRED




Detail 22




Detail 22

STEP 33







PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED





Detail 22

STEP 34



PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED



STEP 35




PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED



STEP 36

PARTS REQUIRED


24 - DOOR x1



HARDWARE REQUIRED


R  12

TOOLS REQUIRED



Detail 23

Detail 24



Detail 23


Detail 24


STEP 37


PARTS REQUIRED

12 - STOOL SIDE PANEL (GREEN) x2

HARDWARE REQUIRED



G  04

H  01


N  04
Ø6,0 x 30mm

P  04

TOOLS REQUIRED



Detail 1



Detail 4

STEP 38


PARTS REQUIRED


13 - STOOL CROSSPIECE (YELLOW) x2

14 - STOOL SEAT x1



HARDWARE REQUIRED

H  01


M  04

N  Ø6,0 x 30mm 04


TOOLS REQUIRED



Detail 1



Detail 9




STEP 39

PARTS REQUIRED

12 - STOOL SIDE PANEL (GREEN) x2

13 - STOOL CROSSPIECE (YELLOW) x2




HARDWARE REQUIRED

B  Ø4,0 x 50mm 04


H  01

R  04


TOOLS REQUIRED



Detail 1




Detail 25




STEP 40


PARTS REQUIRED

14 - STOOL SEAT x1








HARDWARE REQUIRED

H  01

L  04

TOOLS REQUIRED




Detail 1


Detail 21


STEP 41

PARTS REQUIRED





HARDWARE REQUIRED

E  04
MQ M4 x 20mm


Q  02

TOOLS REQUIRED




 See the last page

Detail 25




Detail 25




STEP 42




PARTS REQUIRED




HARDWARE REQUIRED




TOOLS REQUIRED





Height Adjustment



Internal Adjustment



Depth Adjustment






WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.



| | |
|--|--|
| | A Flan Head Screw Ø4,0 x 14mm (2x) |
| | S Washer (4x) |
| | O Strap (2x) |