


OLIVER 4 DOOR WARDROBE ASSEMBLY INSTRUCTIONS



IMPORTANT FOR DOMESTIC USE ONLY PLEASE READ BEFORE YOU CONTINUE FURTHER

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTINGS KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE. DO NOT OVERTIGHTEN FIXING.

FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET) DO NOT USE POLISH, DETERGENT OR CHEMICAL CLEANERS.






















THE SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.




PART LIST

| Part Number | Part Code | Part Description | Quantity | Carton |
|-------------|---------------------|---------------------|----------|--------|
| 1 | S100-101-207-EU1-01 | Centre Panel | 1 | 2/3 |
| 2 | S100-101-207-EU1-02 | Shelf Panel - Left | 1 | 1/3 |
| 3 | S100-101-207-EU1-03 | Shelf Panel - Right | 1 | 2/3 |
| 4 | S100-101-207-EU1-04 | Side Panel - Left | 1 | 1/3 |
| 5 | S100-101-207-EU1-05 | Side Panel - Right | 1 | 1/3 |
| 6 | S100-101-207-EU1-06 | Bottom Panel | 1 | 2/3 |
| 7 | S100-101-207-EU1-07 | Top Panel | 1 | 2/3 |
| 8 | S100-101-207-EU1-08 | Back Panel I | 2 | 1/3 |
| 9 | S100-101-207-EU1-09 | Back Panel II | 2 | 1/3 |
| 10 | S100-101-207-EU1-10 | Door - Left & Right | 2 | 3/3 |
| 11 | S100-101-207-EU1-11 | Door - Centre | 2 | 3/3 |


HARDWARE LIST

| | | | |
|---|-------------------------------------------------------------------------------------|-------------------------|--------|
| A |  | DOWEL 6 X 30MM | 20 PCS |
| B |  | CAM BOLT + CAM NUT | 8 SETS |
| C |  | SCREW M6 X 50MM | 12 PCS |
| D |  | SCREW M3.5 X 16MM | 28 PCS |
| E |  | TACK | 58 PCS |
| F |  | SCREW M4 X 32MM | 12 PCS |
| G |  | HANDLE | 4 PCS |
| H |  | TAPPING SCREW M8 X 12MM | 24 PCS |
| I |  | ALLEN KEY | 1 PC |
| J |  | HANDLE SCREW 20MM | 8 PCS |
| K |  | SCREW M3.5 X 12MM | 8 PCS |
| L |  | L PVC FOOT | 2 PCS |
| M |  | SQUARE PVC FOOT | 3 PCS |
| N |  | HINGES 7/8 | 6 PCS |
| O |  | HINGES 5/8 | 6 PCS |
| P |  | PVC STOPPER | 4 PCS |
| Q |  | HANGING RAIL | 2 PCS |
| R |  | PLASTIC H STRIP | 3 PCS |
| S |  | HANGING RAIL SUPPORT | 4 PCS |
| T |  | ANTI - TIP STRAP | 2 PCS |
| U |  | SCREW M4 X 16MM | 2 PCS |



(SCREWDRIVER NOT PROVIDED)

USE A FLAT HEAD SCREWDRIVER TO TIGHTEN THE CAM NUTS. A QUARTER TURN CLOCKWISE IS ALL THAT IS NEEDED.



STEP 1 - PUSH CAM BOLT INTO INSERT

STEP 2 - ALIGN THE CAM BOLT WITH THE HOLE AND PUSH TOGETHER UNTIL FLUSH. (MAKE SURE THE ARROW OF THE CAM LOCK IS POINTING TOWARD ON THE EDGE OF THE PANEL.)

STEP 3 - THE HEAD OF THE BOLT GOES INTO THE WIDE MOUTH OF THE CAM LOCK. YOU THEN TURN THE LOCK SO THE NARROW PART CLOSES OVER THE BOLT.

STEP 1


PARTS REQUIRED

1 - CENTRE PANEL x1

HARDWARE REQUIRED




A  04

B  04

K  04

S  02

TOOLS REQUIRED



STEP 2

PARTS REQUIRED

2 - SHELF PANEL - LEFT x1



3 - SHELF PANEL - RIGHT x1

HARDWARE REQUIRED

A  08

B  08

TOOLS REQUIRED



STEP 3

PARTS REQUIRED

4 - SIDE PANEL - LEFT x1

5 - SIDE PANEL - RIGHT x1

HARDWARE REQUIRED




A  08

B  04

K  04

S  02

TOOLS REQUIRED




STEP 4

PARTS REQUIRED

6 - BOTTOM PANEL x1




7 - TOP PANEL x1

HARDWARE REQUIRED

D  04

P  04

TOOLS REQUIRED





STEP 5

PARTS REQUIRED

- 1 - CENTRE PANEL x1
- 2 - SHELF PANEL - LEFT x1
- 3 - SHELF PANEL - RIGHT x1
- 4 - SIDE PANEL - LEFT x1
- 5 - SIDE PANEL - RIGHT x1

HARDWARE REQUIRED


TOOLS REQUIRED



STEP 6

PARTS REQUIRED


- 6 - BOTTOM PANEL x1



HARDWARE REQUIRED

- C 06


TOOLS REQUIRED




STEP 7


PARTS REQUIRED

7 - TOP PANEL x1



HARDWARE REQUIRED



F  12

C  06

L  02

M  03

TOOLS REQUIRED




STEP 8


PARTS REQUIRED

8 - BACK PANEL I x2

9 - BACK PANEL II x2





HARDWARE REQUIRED

E  58

R  03

TOOLS REQUIRED






STEP 9



PARTS REQUIRED

| | |
|--------------------------|----|
| 10 - DOOR - LEFT & RIGHT | x2 |
| 11 - DOOR - CENTRE | x2 |

HARDWARE REQUIRED

| | | |
|---|-----------------------------------------------------------------------------------|----|
| D |  | 24 |
| N |  | 06 |
| O |  | 06 |


TOOLS REQUIRED







STEP 10

PARTS REQUIRED



| | |
|--------------------------|----|
| 10 - DOOR - LEFT & RIGHT | x1 |
| 11 - DOOR - CENTRE | x1 |



HARDWARE REQUIRED

| | | |
|---|-------------------------------------------------------------------------------------|----|
| H |  | 12 |
| G |  | 02 |
| J |  | 04 |
| Q |  | 02 |


TOOLS REQUIRED



STEP 11

PARTS REQUIRED



| | |
|--------------------------|----|
| 10 - DOOR - LEFT & RIGHT | x1 |
| 11 - DOOR - CENTRE | x1 |




HARDWARE REQUIRED

| | | |
|---|--|----|
| H | | 12 |
| G | | 02 |
| J | | 04 |


TOOLS REQUIRED



1. VERTICAL ADJUSTMENT VIA SLOT IN THE MOUNTING PLATE




2. LATERAL ADJUSTMENT BY SCREW ADJUSTING



3. FRONT-TO-BACK BY THE SLACKING THE HINGE ARM MOUNTING SCREW

YOU SHOULD RE-ADJUST SCREWS AS SHOWN TO ALIGN DOOR ONCE HINGES HAVE BEEN ATTACHED.



STEP 12

PART REQUIRED



HARDWARE REQUIRED

| | | |
|---|--|----|
| T | | 02 |
| U | | 02 |



TOOLS REQUIRED





WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.



OLIVER 3 DRAWER CHEST ASSEMBLY INSTRUCTIONS



IMPORTANT FOR DOMESTIC USE ONLY PLEASE READ BEFORE YOU CONTINUE FURTHER

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTINGS KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE. DO NOT OVERTIGHTEN FIXING.

FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET) DO NOT USE POLISH, DETERGENT OR CHEMICAL CLEANERS.




















THE SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.




PART LIST

| Part Number | Part Code | Part Description | Quantity | Carton |
|-------------|---------------------|--------------------------|----------|--------|
| 1 | S100-102-189-EU1-01 | Side Panel - Left | 1 | 1/1 |
| 2 | S100-102-189-EU1-02 | Front Crossbars | 2 | 1/1 |
| 3 | S100-102-189-EU1-03 | Side Panel - Right | 1 | 1/1 |
| 4 | S100-102-189-EU1-04 | Bottom Panel | 1 | 1/1 |
| 5 | S100-102-189-EU1-05 | Top Panel | 1 | 1/1 |
| 6 | S100-102-189-EU1-06 | Back Panel | 2 | 1/1 |
| 7 | S100-102-189-EU1-07 | Drawer Back | 3 | 1/1 |
| 8 | S100-102-189-EU1-08 | Drawer Side - Left | 3 | 1/1 |
| 9 | S100-102-189-EU1-09 | Drawer Side - Right | 3 | 1/1 |
| 10 | S100-102-189-EU1-10 | Drawer Front | 3 | 1/1 |
| 11 | S100-102-189-EU1-11 | Drawer Base | 3 | 1/1 |
| 12 | S100-102-189-EU1-12 | Drawer Base Support Rail | 3 | 1/1 |


HARDWARE LIST

| | | | |
|---|-------------------------------------------------------------------------------------|-----------------------|---------|
| A |  | DOWEL 6 X 30MM | 36 PCS |
| B |  | CAM BOLT + CAM NUT | 17 SETS |
| C |  | SCREW M6 X 50MM | 4 PCS |
| D |  | SCREW M3.5 X 16MM | 18 PCS |
| E |  | TACK | 28 PCS |
| F |  | SCREW M4 X 32MM | 10 PCS |
| G |  | HANDLE | 3 PCS |
| H |  | SCREW M4 X 30MM | 6 PCS |
| I |  | ALLEN KEY | 1 PC |
| J |  | HANDLE SCREW 20MM | 6 PCS |
| K |  | SCREW M3.5 X 12MM | 48 PCS |
| L |  | L PVC FOOT | 2 PCS |
| M |  | SQUARE PVC FOOT | 2 PCS |
| N |  | SCREW M4 X 38MM | 6 PCS |
| O |  | DRAWER RUNNER A - L/R | 6 PCS |
| P |  | DRAWER RUNNER B - L/R | 6 PCS |
| Q |  | PLASTIC H STRIP | 1 PC |
| R |  | ANTI - TIP STRAP | 2 PCS |
| S |  | SCREW M4 X 16MM | 2 PCS |



(SCREWDRIVER NOT PROVIDED)

USE A FLAT HEAD SCREWDRIVER TO TIGHTEN THE CAM NUTS. A QUARTER TURN CLOCKWISE IS ALL THAT IS NEEDED.



STEP 1 - PUSH CAM BOLT INTO INSERT

STEP 2 - ALIGN THE CAM BOLT WITH THE HOLE AND PUSH TOGETHER UNTIL FLUSH. (MAKE SURE THE ARROW OF THE CAM LOCK IS POINTING TOWARD ON THE EDGE OF THE PANEL.)

STEP 3 - THE HEAD OF THE BOLT GOES INTO THE WIDE MOUTH OF THE CAM LOCK. YOU THEN TURN THE LOCK SO THE NARROW PART CLOSES OVER THE BOLT.

STEP 1

PARTS REQUIRED


1 - SIDE PANEL - LEFT x1

HARDWARE REQUIRED




A  04

B  02

K  12

O  03

TOOLS REQUIRED



STEP 2


PARTS REQUIRED


3 - SIDE PANEL - RIGHT x1

HARDWARE REQUIRED




A  04

B  02

K  12

O  03

TOOLS REQUIRED



STEP 3

PARTS REQUIRED

2 - FRONT CROSSBARS x2



5 - TOP PANEL x1

HARDWARE REQUIRED

A  04

B  04

TOOLS REQUIRED



STEP 4



PARTS REQUIRED

1 - SIDE PANEL - LEFT x1

2 - FRONT CROSSBARS x2

HARDWARE REQUIRED


TOOLS REQUIRED



STEP 5



PARTS REQUIRED

3 - SIDE PANEL - RIGHT x1



HARDWARE REQUIRED


TOOLS REQUIRED




STEP 6

PARTS REQUIRED


4 - BOTTOM PANEL x1



HARDWARE REQUIRED

C  04


TOOLS REQUIRED




STEP 7

PARTS REQUIRED

5 - TOP PANEL x1






HARDWARE REQUIRED

F  10

L  02

M  02


TOOLS REQUIRED




STEP 8

PARTS REQUIRED

6 - BACK PANEL x2





HARDWARE REQUIRED

E  28

Q  01

TOOLS REQUIRED







STEP 9



PARTS REQUIRED

| | |
|-----------------------|----|
| 7 - DRAWER BACK | x3 |
| 8 - DRAWER SIDE-LEFT | x3 |
| 9 - DRAWER SIDE-RIGHT | x3 |
| 10 - DRAWER FRONT | x3 |

HARDWARE REQUIRED

| | | |
|---|-----------------------------------------------------------------------------------|----|
| A |  | 24 |
| B |  | 09 |
| B |  | 06 |
| N |  | 06 |


TOOLS REQUIRED






STEP 10

PARTS REQUIRED



| | |
|------------------|----|
| 11 - DRAWER BASE | x3 |
|------------------|----|



HARDWARE REQUIRED

| | | |
|---|-------------------------------------------------------------------------------------|----|
| G |  | 03 |
| J |  | 06 |
| K |  | 24 |


TOOLS REQUIRED



STEP 11


PARTS REQUIRED


12 -DRAWER BASE SUPPORT RAIL x3




HARDWARE REQUIRED




B  03

D  18

H  06



P  06

TOOLS REQUIRED




STEP 12



PARTS REQUIRED



HARDWARE REQUIRED





TOOLS REQUIRED





STEP 13PART REQUIREDHARDWARE REQUIREDR  02S  02TOOLS REQUIRED**WARNING**

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.



OLIVER 3 DRAWER BEDSIDE ASSEMBLY INSTRUCTIONS



IMPORTANT FOR DOMESTIC USE ONLY PLEASE READ BEFORE YOU CONTINUE FURTHER

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTINGS KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE. DO NOT OVERTIGHTEN FIXING.

FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET) DO NOT USE POLISH, DETERGENT OR CHEMICAL CLEANERS.


















THE SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.




PART LIST

| <u>Part Number</u> | <u>Part Code</u> | <u>Part Description</u> | <u>Quantity</u> | <u>Carton</u> |
|--------------------|---------------------|-------------------------|-----------------|---------------|
| 1 | S100-103-099-EU1-01 | Side Panel - Left | 1 | 1/1 |
| 2 | S100-103-099-EU1-02 | Side Panel - Right | 1 | 1/1 |
| 3 | S100-103-099-EU1-03 | Bottom Panel | 1 | 1/1 |
| 4 | S100-103-099-EU1-04 | Top Panel | 1 | 1/1 |
| 5 | S100-103-099-EU1-05 | Back Panel | 1 | 1/1 |
| 6 | S100-103-099-EU1-06 | Drawer Back | 3 | 1/1 |
| 7 | S100-103-099-EU1-07 | Drawer Side - Left | 3 | 1/1 |
| 8 | S100-103-099-EU1-08 | Drawer Side - Right | 3 | 1/1 |
| 9 | S100-103-099-EU1-09 | Drawer Front | 3 | 1/1 |
| 10 | S100-103-099-EU1-10 | Drawer Base | 3 | 1/1 |


HARDWARE LIST

| | | | |
|---|-------------------------------------------------------------------------------------|-----------------------|---------|
| A |  | DOWEL 6 X 30MM | 32 PCS |
| B |  | CAM BOLT + CAM NUT | 10 SETS |
| C |  | SCREW M6 X 50MM | 4 PCS |
| D |  | SCREW M3.5 X 16MM | 18 PCS |
| E |  | TACK | 18 PCS |
| F |  | SCREW M4 X 32MM | 10 PCS |
| G |  | HANDLE | 3 PCS |
| H |  | SCREW M4 X 38MM | 6 PCS |
| I |  | ALLEN KEY | 1 PC |
| J |  | HANDLE SCREW 20MM | 6 PCS |
| K |  | SCREW M3.5 X 12MM | 36 PCS |
| L |  | L PVC FOOT | 2 PCS |
| M |  | SQUARE PVC FOOT | 2 PCS |
| N |  | DRAWER RUNNER A - L/R | 6 PCS |
| O |  | DRAWER RUNNER B - L/R | 6 PCS |
| P |  | ANTI - TIP STRAP | 2 PCS |
| Q |  | SCREW M4 X 16MM | 2 PCS |



(SCREWDRIVER NOT PROVIDED)

USE A FLAT HEAD SCREWDRIVER TO TIGHTEN THE CAM NUTS. A QUARTER TURN CLOCKWISE IS ALL THAT IS NEEDED.



STEP 1 - PUSH CAM BOLT INTO INSERT

STEP 2 - ALIGN THE CAM BOLT WITH THE HOLE AND PUSH TOGETHER UNTIL FLUSH. (MAKE SURE THE ARROW OF THE CAM LOCK IS POINTING TOWARD ON THE EDGE OF THE PANEL.)

STEP 3 - THE HEAD OF THE BOLT GOES INTO THE WIDE MOUTH OF THE CAM LOCK. YOU THEN TURN THE LOCK SO THE NARROW PART CLOSES OVER THE BOLT.

STEP 1


PARTS REQUIRED


1 - SIDE PANEL - LEFT x1

HARDWARE REQUIRED




A  04

B  02

K  12

N  03

TOOLS REQUIRED



STEP 2


PARTS REQUIRED


2 - SIDE PANEL - RIGHT x1

HARDWARE REQUIRED




A  04

B  02

K  12

N  03

TOOLS REQUIRED



STEP 3


PARTS REQUIRED

4 - TOP PANEL x1

HARDWARE REQUIRED

B  04

TOOLS REQUIRED



STEP 4

PARTS REQUIRED

1 - SIDE PANEL - LEFT x1



2 - SIDE PANEL - RIGHT x1

3 - BOTTOM PANEL x1

HARDWARE REQUIRED

C  04


TOOLS REQUIRED




STEP 5

PARTS REQUIRED

4 - TOP PANEL x1






HARDWARE REQUIRED

F  10

L  02

M  02


TOOLS REQUIRED



STEP 6

PARTS REQUIRED



5 - BACK PANEL x1



HARDWARE REQUIRED

E  18

TOOLS REQUIRED






STEP 7



PARTS REQUIRED

| | |
|-----------------------|----|
| 6 - DRAWER BACK | x3 |
| 7 - DRAWER SIDE-LEFT | x3 |
| 8 - DRAWER SIDE-RIGHT | x3 |
| 9 - DRAWER FRONT | x3 |

HARDWARE REQUIRED

| | | |
|---|-----------------------------------------------------------------------------------|----|
| A |  | 24 |
| B |  | 06 |
| H |  | 06 |


TOOLS REQUIRED






STEP 8

PARTS REQUIRED



| | |
|------------------|----|
| 10 - DRAWER BASE | x3 |
|------------------|----|



HARDWARE REQUIRED


| | | |
|---|-------------------------------------------------------------------------------------|----|
| G |  | 03 |
| J |  | 06 |
| K |  | 12 |

TOOLS REQUIRED





STEP 9




PARTS REQUIRED



HARDWARE REQUIRED





TOOLS REQUIRED



X3


STEP 10



PARTS REQUIRED



HARDWARE REQUIRED

TOOLS REQUIRED



STEP 11PART REQUIREDHARDWARE REQUIREDTOOLS REQUIRED**WARNING**

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.

