


BERGEN 2 DRAWER COFFEE TABLE

OAK EFFECT/WHITE/GREY

ASSEMBLY INSTRUCTIONS



IMPORTANT FOR DOMESTIC USE ONLY



PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.












TOOLS REQUIRED

**PARTS LIST*****Please Note:***

The below parts have all been stamped with the part number to help identify them during assembly.


Part Number	Part Code	Part Description	Quantity	Carton
1	S300-301-051-AY1-01	Base Panel	1	1/1
2	S300-301-051-AY1-02	Lower Division Panel	1	1/1
3	S300-301-051-AY1-03	Back Crossbeam	1	1/1
4	S300-301-051-AY1-04	Shelf Panel	1	1/1
5	S300-301-051-AY1-05	Left Side Panel	1	1/1
6	S300-301-051-AY1-06	Right Side Panel	1	1/1
7	S300-301-051-AY1-07	Upper Division Panel	1	1/1
8	S300-301-051-AY1-08	Top Panel	1	1/1
9	S300-301-051-AY1-09	Left Drawer Front	1	1/1
10	S300-301-051-AY1-10	Right Drawer Front	1	1/1
11	S300-301-051-AY1-11	Drawer Side	4	1/1
12	S300-301-051-AY1-12	Drawer Bottom	2	1/1
13	S300-301-051-AY1-13	Drawer Back Panel	2	1/1

FITTINGS LIST


<p>A</p>  <p>2/+ Dowel Ø6,0 x 30mm (34x)</p>	<p>B</p>  <p>2/+ Cam Bolt (17x)</p>	<p>C</p>  <p>2/+ Cam Nut (19x)</p>	<p>D</p>  <p>Double Cam Bolt (1x)</p>
<p>E</p>  <p>1/+ Pan Head Screw Ø3,5 x 40mm (7x)</p>	<p>F</p>  <p>2/+ Pan Head Screw Ø4,0 x 14mm (16x)</p>	<p>G</p>  <p>2/+ Flat head Screw Ø3,5 x 12mm (20x)</p>	<p>H</p>  <p>2/+ Hole Plugs(16x)</p>
<p>I</p>  <p>Drawer Runners 350mm (2x)</p>	<p>J</p>  <p>Metal Leg (4x)</p>	<p>K</p>  <p>Glue (2x)</p>	

TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT. ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT
CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE




CORRECT
WRONG



Cam bolt head needs to be in centre

CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example below)




STEP 1




PARTS REQUIRED

8 - TOP PANEL x1

HARDWARE REQUIRED

B  05

TOOLS REQUIRED




STEP 2

PARTS REQUIRED



4 - SHELF PANEL x1

HARDWARE REQUIRED

A  04

K  01

TOOLS REQUIRED








STEP 3





PARTS REQUIRED

6 - RIGHT SIDE PANEL x1


HARDWARE REQUIRED

- A  03
- B  02
- G  03
- I  01
- K  01


TOOLS REQUIRED



Detail 1



Detail 2








Detail 3

STEP 4





PARTS REQUIRED

5 - LEFT SIDE PANEL x1


HARDWARE REQUIRED

- A  03
- B  02
- G  03
- I  01
- K  01


TOOLS REQUIRED



Detail 1



Detail 2




Detail 3


STEP 5

PARTS REQUIRED



7 - UPPER DIVISION PANEL x1

HARDWARE REQUIRED

A  04

K  01

TOOLS REQUIRED




Detail 2

STEP 6

PARTS REQUIRED


2 - DIVISION PANEL x1

HARDWARE REQUIRED





A  04

G  06


I  02

K  01

TOOLS REQUIRED



Detail 2



Detail 3

STEP 7

PARTS REQUIRED



3 - BACK CROSSBEAM x1

HARDWARE REQUIRED

A  08

K  01

TOOLS REQUIRED



STEP 8

PARTS REQUIRED


2 - LOWER DIVISION PANEL x1

4 - SHELF PANEL x1

7 - UPPER DIVISION PANEL x1

HARDWARE REQUIRED



C  02

D  01

H  02

K  01


TOOLS REQUIRED



STEP 9

PARTS REQUIRED

5 - LEFT SIDE PANEL x1








HARDWARE REQUIRED

C   02

K  01

TOOLS REQUIRED




Detail 5

Detail 8



STEP 10

PARTS REQUIRED

6 - RIGHT SIDE PANEL x1








HARDWARE REQUIRED

C   02

K  01

TOOLS REQUIRED




Detail 5

Detail 8

STEP 11

PARTS REQUIRED

8 - TOP PANEL x1








HARDWARE REQUIRED

C 05

H 05

K 01

TOOLS REQUIRED




Detail 4

Detail 8

STEP 12

PARTS REQUIRED

3 - BACK CROSSBEAM x1







HARDWARE REQUIRED

E 01

H 01

K 01

TOOLS REQUIRED




Detail 6

Detail 8


STEP 13

PARTS REQUIRED




1 - BASE PANEL x1




HARDWARE REQUIRED



TOOLS REQUIRED




Detail 6





Detail 8

STEP 14




PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED



Detail 7

STEP 15

PARTS REQUIRED

9 - LEFT DRAWER FRONT x1


10 - RIGHT DRAWER FRONT x1

11 - DRAWER SIDE x4

13 - DRAWER BACK PANEL x2





HARDWARE REQUIRED

A  08

B  08

K  01

TOOLS REQUIRED



STEP 16


PARTS REQUIRED

11 - DRAWER SIDE x4

12 - DRAWER BOTTOM x2

13 - DRAWER BACK PANEL x2






HARDWARE REQUIRED

C  04

H  04

K  01

TOOLS REQUIRED




STEP 17



PARTS REQUIRED

9 - LEFT DRAWER FRONT x1

10 - RIGHT DRAWER FRONT x1








HARDWARE REQUIRED

C   04

H  04

K  GLUE 01

TOOLS REQUIRED




Detail 4



Detail 8

STEP 18

PARTS REQUIRED







HARDWARE REQUIRED

G   08

I  04


TOOLS REQUIRED



Detail 9



STEP 19

PARTS REQUIRED



HARDWARE REQUIRED

TOOLS REQUIRED



Detail 10

TIP
If desired, after assembly use an alcohol cleaner to erase the number printed on the parts.

An illustration of a hand holding a cloth and cleaning a surface. A small number '17' is visible on the surface being cleaned.